



### **How To Guide:**

IPSec VPN Tunnels for Load Balancing



### Introduction

In the past, IPSec VPN tunnels destined for the same remote network could only establish over a single interface, yet it is now possible to form and send traffic over IPSec VPN tunnels on multiple interfaces with the Q-Balancer appliances at both ends, which significantly increases the flexibility of traffic path and routing decisions in VPN deployments.



### Diagram Example

**Branch:** 

Port 1:

WAN 1: example\_1

IP: 203.67.222.40, Subnet: 203.67.222.40/30,

GW:203.67.222.1

Port 2:

WAN 2: example\_2

IP: 100.100.100.6, Subnet:100.100.100.0/29,

GW:100.100.100.1

Port 4:

**Branch LAN:** 10.168.1.0/24, Interface:

10.168.1.254

HQ:

Port 1:

WAN 1: hq\_1

IP: 103.67.222.47, Subnet: 103.67.222.40/29,

GW:103.67.222.41

Port 2:

WAN 2: hq\_2


IP: 118.169.192.20, Subnet:

118.169.192.20/30, GW:118.169.192.21

Port 4:

**HQ LAN:** 20.20.20.0/24, Interface:

20.20.20.254





# Requirement

In this case, the solution is required to:

- > Failover LAN-to-LAN access between two IPSec tunnels.
- > Find the optimal path for critical network services.



Follow the steps below to configure IPSec VPN Tunnels for load balancing on the branch appliance with the IP details given:

- 1. WAN > ADD
- 2. LAN > ADD
- 3. VPN > IPSec > ADD
- 4. Object > DPS > ADD
- 5. Policy Routing > ADD



### WAN > ADD > Static

Name			
example_1			
Port			
Port 1	•		
Path Monitoring			
dns_ipv4			
Subnet			
203.67.222.40/30			
IP			
203.67.222.40			
Gateway			
203.67.222.1			
ок	CANCEL		



### WAN > ADD > Static

Name			
example_2			
Port			
Port 2	▼		
Path Monitoring	J		
dns_ipv4			•
Subnet			
100.100.100	.0/29		
IP			
100.100.100	).6		
Gateway			
100.100.100	.1		
ок	CANCEL		




# WAN configuration on the branch appliance is done as follows:

### WAN

ADI	) <b>~</b>	DELET	E							
Status	Type ↑↓	Name 📬	Port ᡝ	Interface 1	Subnet	$\uparrow \downarrow$	IP	$\uparrow\downarrow$	Gateway	$\uparrow \downarrow$
~	Static	example_1	Port 1	eth0_6	203.67.222.	40/30	203.67.222	.40	203.67.222	2.1
~	Static	example_2	Port 2	eth1_2	100.100.100	0.0/29	100.100.10	0.6	100.100.10	0.1




### LAN > ADD





## LAN configuration on the branch appliance is done as follows:





In the Q-Balancer there are two types of *IPSec VPN Tunnels*, General and QB2QB. General is to establish IPSec VPN with third-party VPN solution, while QB2QB is to establish IPSec VPN between the Q-Balancer appliances. In this case, we will use QB2QB to build IPSec tunnels. Adding *IPSec Tunnels* on the branch appliance is done as follows:




/ 2.9

Mbps

15.3

Enabled Name IPSec\_tun\_1 Type O General O QB2QB Tunnel ID Pre-Shared Key qbalancer Down/Up Speed









Select the IP address to be the remote peer

Remote

103.67.222.47

IKE ID

103.67.222.47

Ignored


Network

IP or Subnet





Leave rest of parameters default.






The procedure of adding second IPSec Tunnel is same as the first one, and so is skipped in this guide. The IPSec tunnels on the branch appliance is done as follows:

Name ↑↓	Type ↑↓	Tunnel ID $\uparrow\downarrow$	Interface 1	Local ↑↓	Local IKE ID $\uparrow\downarrow$	Local Network 1
IPSec_tun_1	QB2QB	1	ipsec0	203.67.222.40	203.67.222.40	-
IPSec_tun_2	QB2QB	2	ipsec1	100.100.100.6	100.100.100.6	-
Remote ↑↓	Remote I	KEID ↑↓ F	Remote Network 立	Pre-Shared Key	↑↓ Exchange I	Mode ↑↓ Other
103.67.222.47	103.67.	222.47	-	qbalancer	Mai	ı •
118.169.192.20	118.169	.192.20	-	qbalancer	Maii	¬ •



# Objects > DPS > ADD


Adding a **DPS** object for **IPSec VPN** tunnels on the branch appliance:



**Note**: All algorithms are applicable for VPN load balancing.



# Policy Routing > ADD



Add HQ subnet here for policy routing.

Choose the DPS newly created for IPSec VPN.



# **Policy Routing**

Policy Routing for IPSec VPN Tunnels on the branch appliance is done as follows:

Source	$\uparrow \downarrow$	Destination	↑↓ Services ↑↓	Schedules 1	Pool ↑↓	NAT $\uparrow\downarrow$
branch_LAN	←→	hq_LAN	Any	Always	branch_IPSec_balance	No




# Follow the steps below to configure IPSec VPN Tunnels for load balancing on the HQ appliance with the IP details given:

- 1. WAN > ADD
- 2. LAN > ADD
- 3. VPN > IPSec > ADD
- 4. Object > DPS > ADD
- 5. Policy Routing > ADD



### WAN > ADD > Static






### WAN > ADD > Static

Name			
hq_2			
Port			
Port 2	•		
Path Monitoring			
dns_ipv4			
Subnet			
118.169.192.20/30	)		
IP			
118.169.192.20			
Gateway			
118.169.192.21			
OK	CANCEL		



# WAN configuration on the HQ appliance is done as follows:

#### WAN





### LAN > ADD

Name			
hq_LAN			
Related ISP			
Auto			•
Port			
Port 4	▼		
Subnet 20.20.20.0/24			
Route			
<ul><li>Interface</li><li>IP</li><li>20.20.20.254</li></ul>	O Gateway		
DHCP			
Enabled			
ОК	CANCEL		



20.20.20.254

### LAN configuration on the HQ appliance is done as follows:

# ADD DELETE Name ↑↓ Port ↑↓ Interface ↑↓ Subnet ↑↓ Route ↑↓ IP ↑↓

Port 4

eth3\_11 20.20.20.0/24


Interface

hq\_LAN




Enabled Name IPSec\_tun\_1 Type O General O QB2QB Tunnel ID Pre-Shared Key qbalancer Down/Up Speed / 2.9 15.3 Mbps








Select the IP address to be the remote peer.





Leave rest of parameters default.





The procedure of adding second IPSec Tunnel is same as the first one, and so is skipped in this guide. The IPSec tunnels on the HQ appliance is done as follows:

Name ↑↓	Type ↑↓	Tunnel ID 1	Interface 🔱	Local ↑↓	Local IKE ID ↑↓	Local Network 👈
IPSec_tun_1	QB2QB	1	ipsec0	103.67.222.47	103.67.222.47	-
IPSec_tun_2	QB2QB	2	ipsec1	118.169.192.20	118.169.192.20	-



Remote ↑↓	Remote IKE ID $\uparrow\downarrow$	Remote Network 1	Pre-Shared Key ↑↓	Exchange Mode 1	Other
203.67.222.40	203.67.222.40	-	qbalancer	Main	•
100.100.100.6	100.100.100.6	-	qbalancer	Main	•




# Objects > DPS > ADD

Adding a **DPS** object for **IPSec VPN** tunnels on the HQ appliance:

Name				
hq_IPSec_ba	lance			
Backup Pool				
None				
Algorithm				
Weighted Ro	und Robin by Cor	nnection		
Links				
IPSec_tu	in_1, IPSec_tun_:	2		
Weight				
IPSec_tu	n_1		IPSec_tun_2	
•			•	
Proxy				
ОК	CANCEL			



# Policy Routing > ADD




Add branch subnet here for policy routing.



# **Policy Routing**

Policy Routing for IPSec VPN on the *HQ* appliance is done as follows:



For reference, the following is the counterpart setting on the **branch** appliance:

Source	$\uparrow \downarrow$	Destination	↑↓ Services ↑↓	Schedules 1	Pool ↑↓	NAT $\uparrow\downarrow$
branch_LAN	←→	hq_LAN	Any	Always	branch_IPSec_balance	No



### Done!

Check if the LAN hosts at the branch are able to ping hosts at the HQ now.